

Introduction

Welcome to a new dimension of safety and security for your loved ones and assets with your purchase of the TrackmateGPS MINI SPY and its advanced technology. The MINI SPY lets you know where your loved one or car is at all times. It can even signal you if someone exceeds your predetermined speed limit or enters an undesirable area.

The MINI SPY is ideal for commercial or personal use, simple to install and easy to use.

Registration

If this is your first TrackmateGPS™ tracking device you will need to create an account at www.trackmategps.com.

1. On the Sign Up page, you will be prompted to fill out an account information form.
2. Next you will be prompted to enter your credit card information. You will not be charged at this point, but we will run verification on the card. You will not be able to register a new device without a valid card on file.
3. You will be redirected to the “Register Device” page where you will be able to enter your device’s serial number which can be found on the device and on the box.

Tracking systems for personal use. GPS Tracker alerts parents a new resource to help keep young, new driver safe as well as ensure that property and people are secure.

REGISTER YOUR ACCOUNT

“REGISTER YOUR ACCOUNT” button as it appears on the homepage

4. On this page you will be prompted to select one of the service plans:
 - a. Basic
 - b. Premium
 - c. Platinum
5. Due to the possibility that you may be tracking an asset in a different country, you will select the country where your device is located.
6. Any subsequent devices may be registered by navigating to the “Register Device” page located under the “Devices” section of the

website’s header menu.

Failure to provide the correct information will cause the activation to fail.

Using Your Device

Note: Fully charge your MINI SPY’s battery before first use.

1. Charge your device with the provided mini USB charger for 5 hours, or until the red light is steady.
2. To turn your device on or off hold the power button down for 3 seconds.
3. LEDs will flash initially, and enter normal working state after a few seconds. See the table at the back of this guide for a description of the LED states.
4. Device will operate best in an open area with a clear view of the sky. If you have trouble with the initial activation of the unit take it outside, and walk around for a few minutes.



LED	Event	State
GREEN LED (Cellular)	Searching for network	Fast flash
	The device is registered on the network.	Slow flash
	Power off	Dark
BLUE LED (GPS)	GPS has fixed a position.	Solid
	GPS is in the process of fixing.	Fast flash
	GPS is on and GPS data is wrong.	Slow flash
	GPS is off.	Dark
	150 seconds have passed after power on when <LED on> is 0.	Dark
RED LED (Power)	Power on and normal	Dark
	Charger inserted and charging completed	Solid
	Charger inserted and charging	Fast flash
	Power button is pressed to power off the device.	Fast flash
	Abnormal	Fast flash
	Low power alert	Slow flash

Thank you for purchasing the TrakmateGPS MINI SPY. We are confident you will find the service and features a valuable part of your personal or professional life.

Please contact us with any questions you may have.
Any review on Amazon will be greatly appreciated.

QUICK START GUIDE

Product Information • Registration • Using Your Device

Version 1
Published 2.6.2020

trackmategps™

www.trackmategps.com
718-878-4056
support@trackmategps.com

MINI SPY



Specifications

Operating Bands	B2/B4/B12/B13
Accuracy	8 ft.
Dimensions	1.57 x 1.05 x 3.06 in.
Weight	3.28 Oz.
Battery	Li-Polymer 2600 mAh
Operating Temperature	-4° ~ 131° F
Water Resistance	IPX5 Compliant
Charging Voltage	5V

- Internal 3-axis accelerometer for power saving and motion detection
- Thumb sized button allowing emergency SOS alert.
- Low power consumption, long standby time with internal battery
- Water resistant

Lifetime warranty covers hardware defects not caused by negligence. TrackmateGPS is not responsible for service interruption due to service providers changing cellular technologies.

Do not use device on airplane or near medical equipment